Assignment - 8

<u>Aim</u>: To Identify different components of a PC and steps for assembling & disassembling of a PC.

Identification of different PC components:


1) Motherboard:



The motherboard is an important computer component because it's what everything else connects to! The motherboard is a decently sized circuit board that lets other components communicate. A motherboard has ports that face outside a PC's case, so you can charge your computer, plug in a monitor, or connect a mouse.

2) Processor:

A CPU, sometimes referred to as a computer's brain, is the workhorse of the machine. It performs the calculations needed by a system, and can vary in speed. The work that a CPU does generates heat, which is why your



computer has a fan inside. A more powerful CPU is necessary for intense computer work like editing high-definition video or programming complex software.

3) Memory (RAM):



The system memory is often called RAM (for random access memory). This is the primary memory, which holds all the programs and data the processor is using at a given time.

4) Case/chassis:

The case is the frame or chassis that houses the motherboard, power supply, disk drives, adapter cards, and any other physical components in the system.



5) Power supply:



True to its name, the power supply powers all other components of the machine. It usually plugs into the motherboard to power the other parts. The power supply connects to either an internal battery (on a laptop) or a plug for an outlet (on a desktop).

6) Floppy drive:

The floppy drive is a simple, inexpensive, low-capacity, removable-media, magnetic storage device.



7) Hard drive:



Since RAM is temporary, your computer needs a place to store data permanently. That's where the hard drive comes in. The traditional hard drive consists of several spinning platters with an arm that physically writes data to the disk. However, these drives are slow and are starting to be replaced by the faster solid-state drives.

8) CD-ROM/DVD-ROM:

CD-ROM (compact disc read-only) and DVD-ROM (digital versatile disc read-only) drives are relatively high-capacity, removable media, optical drives.



9) Keyboard:



The keyboard is the primary device on a PC that is used by a human to communicate with and control a system.

10) Mouse:

Although many types of pointing devices are on the market today, the first and most popular device for this purpose is the mouse.



11) Video card:



A video card is a dedicated unit for handling the output of images to a display. Video cards have their own dedicated RAM for performing these functions. A high-end video card is required to process extremely intense visual functions, such as computer drafting by engineers. Like many components, many types of video cards are available with varying power and prices.

12) Monitor:

The monitor is the main part of a PC. It is the part where the output of the entire process is displayed.



13) Sound card:



It enables the PC to generate complex sounds.

Assembling a PC:

Part 1:

1. Take Inventory:

Before you start, take inventory of your parts. Make sure you have the following components and tools with you.

- 1. Case/ Tower/Cabinet
- 2. Motherboard
- 3. Processor
- 4. HeatSink and CPU Fan
- 5. SMPS
- 6. Hard disk drive
- 7. CD/ DVD drive
- 8. RAM
- 9. CMOS Battery
- 10. A good screwdriver sets

2. Make Space, Make Time:

Building a PC takes space. You can use your dining room table to build your PC. So, make sure you have plenty of working space and a few hours to proceed with minimal interruption. You must work on a flat, stable tabletop surface or bare floor, where you have room to lay out all of the items, to begin with, assemble.

3. Prepare your CPU cabinet:

Now it is time to prepare the case. Remove the case cover from the CPU cabinet.

You need to check Screw brass standoffs are perfectly placed or not. If it is not in a proper position, in that case, you need to position them accurately. (always check the manual and follow their instructions)

4. INSTALL THE MOTHERBOARD:



You must take great care, especially when installing the motherboard. First, remove the motherboard of its packaging and put it on top of the antistatic bag it came in. Remember, you always want to safeguard your components from potentially hazardous static electricity.

- 1. You need to secure the motherboard onto the PC case/chassis and inspect carefully for any visible defects.
- 2. Next, review the motherboard handbook, to make sure you are familiar with the motherboard layout and understand which socket is which. Manuals are immensely helpful, usually easy to read, and include illustrations instructions.
- 3. Check the layout of the sockets on the motherboard. And confirm that the ports on your motherboard's back panel match the holes on the case's Input/output (I/O) shield installed in your case. If it is necessary, then remove the old I/O shield by tapping it firmly a few times with the thicker end of a screwdriver. And then replace it with the shield that came with the new motherboard.
- 4. You need carefully position the motherboard on top of the brass standoffs. After that line up all the holes, use the screws that accompanied the case to fasten down the motherboard.
- 5. Don't forget to place the CMOS in the proper position.

5. INSTALL THE PROCESSOR (CPU):



- 1. Use the unlocking mechanism to open the CPU socket which is, usually a lever.
- 2. Carefully line up the pins and place the chip in its socket; it will fit only when oriented correctly. An arrow or a

missing pin on one corner of the chip will show you how to line things up.

- 3. Align with the triangular symbol with the processor and socket key marks, as shown in the Figure.
- 4. Lower the lever to lock the CPU into place.

6. INSTALL THE CPU HEAT SINK:

You should follow the manufacturer instructions to install the heat sink and the cooling fan. If you bought an OEM CPU and a separate heat sink, then you need to spread a thin layer of the thermal grease over the chip. The thermal grease ensures proper transfer of heat.

There are some heat sinks that come with this grease already applied. In that case, you don't need to use thermal grease over the chip.

- 1. Attach the clip that holds the heat sink in place, keeping in mind that it may require a fair amount of force. Again, follow the instructions that came with the heat sink. They will show you how to fit it correctly. If you are in doubt, you can visit the manufacturer's website for more information.
- 2. Plug the CPU fan's power connector into the proper connector on the motherboard.

7. INSTALL RAM MEMORY:

- 1. Unlock the two tabs from both ends of the RAM slot.
- 2. To install the RAM, insert them into the proper sockets and push down firmly but evenly until the clips on both sides of the socket pop into place. If your motherboard supports dual-



channel memory, consult the user manual to determine which pairs of RAM sockets you should use.

8. Install the Power Supply Unit (SMPS):



- 1. Place the SMPS inside the CPU cabinet in the proper position. If you are not able to find the correct location, then check the manual.
- 2. Final steps, to install SMPS, you need to tighten the screw to secure the SMPS to the case.

9. To install HDD:

You can see a 3.5 inch bay inside the CPU cabinet. If you are unable to find it, then check the manual of the case to identify the bay location.

Place the HDD inside the bay properly and tighten the screw.



10. To install CD/DVD:

You can see a 5.25 inch bay inside the CPU cabinet. If you are unable to find it, check the manual of the case to identify the bay location.

Place the CD/DVD inside the CPU cabinet to align with the 5.25-inch bay. And, finally, you need to tighten all the screws to hold firmly.

11. Install Expansion cards:


Expansion cards help to increase the functionality of your computer. You can place Expansion cards on the motherboard.

PCI compatible expansion cards can place on the **PCI slots** of the motherboard.

PCI-e compatible expansion cards can place on the **PCI-e slots** of the motherboard.

Video cards or graphics cards can place on the **AGP slot** of the motherboard.

12. Install Sys/Rear cooling fan:



Find the location where you can place the Sys/Rear cooling Fan. Generally, SYS/Rear cooling can place below the SMPS.

13. Bus cable connection:

Amazingly, bus cable or data cable connections are prime connections. Bus cable helps to share information or data between the storage device and motherboard.

If your motherboard has a SATA Bus connector, then you need to use **SATA cables**. AND if your motherboard has a PATA Bus connector, then you can use **PATA** cable or **IDE cable**.

14. Power Cable connection:



This one is the final step of assembling a CPU. You need to provide power to the different parts of the CPU. Plug the **ATX power connector** from your power supply into the matching port on your motherboard.

1. You can find a **20/24 pins ATX power connector port** on the motherboard. The 20/24 pins ATX power connector cable

- coming from SMPS needs to connect here. Check the lock system in both ends of the connector and the port, and place it properly. As always, refer to your motherboard's manual for the exact locations.
- 2. There is another **4-pins ATX power connector port**, you can find on the motherboard. You can locate this port near the processor socket. You must connect the 4-pins power connector in this port properly.

15. Front Panel connector connection:

Use your motherboard user manual and find the description of front-panel connectors.

First, Attach each of the tiny leads from the power and reset switches. After that, the hard-disk activity lights, the PC speaker, and any front-panel USB to the corresponding pin on your motherboard.

Part2: How to assemble PC:

This one is the final part of assembling a computer system.

- 1. Check your keyboard connector port. If it is a USB connector, then connect your keyboard into the proper USB port. And if it is a PS/2 connector, then connect to the correct, PS/2 port.
- 2. Same steps you need to follow to connect your mouse into the proper port.
- 3. You require a VGA (Video Graphic Array) cable to connect the monitor and CPU. Find the 15 pins male connector on the backside of the CPU cabinet and your monitor. Use the VGA cable to connect the CPU cabinet and the monitor. Finally, you need to tighten the lock screws.
- 4. If you have a speaker, you can connect the speaker on the backside of your CPU cabinet. To get sound from the speaker, you need to plug the speaker's cable with the Aux port.
- 5. And if you have a printer, you can connect the printer on the backside of your CPU cabinet. These days, you can connect your speaker BUS cable on the USB port.

Finally, connects power to the various parts of your computer. You have to connect the power cable with the CPU case, monitor, speaker, and printer.

Check your PC Set-Up:

It is time to turn on your system and check your PC set up. Make sure the keyboard, mouse, and monitor are all plugged into the appropriate ports on the back of the PC. Plug the power cord back in, and turn the machine on.

To boot a computer you need hardware and software. Till now you have understood to assemble a computer. If you want to work on that computer you need to install an Operating System.

Disassembling a PC:

Steps for disassembling a PC:

- 1. Unplugged the AC power supply to the PC from the wall socket
- 2. Remove the Cover or chassis or case.
- 3. Unplugged bus cables and ATX power cables
- 4. Remove Adapter Cards if any
- 5. Now Remove the processor and the heatsink and fan
- 6. Remove hard disk and CD/ DVD drives
- 7. Next, remove the Memory Modules
- 8. Remove the Power Supply (SMPS)
- 9. Finally, Remove the Motherboard

1. Unplugged the AC power supply to the PC from the wall socket

This one is the first step to begin a PC disassemble process. Always remember first disconnect all the power supply connected to your computer system before starting to remove parts.

2. Remove the case covering

Loose the screws and remove the case covering to access the inside parts of the CPU cabinet case.

3. Unplugged bus cables and ATX power cables

Disconnect all the cables one by one inside the CPU case. First, disconnect ATX power cables from the motherboard. After that, disconnect power supply cables, bus cables from the HDD/SSD, and motherboard.

4. Remove adapter cards if any

If any adapter is connected then, disconnect the card from the motherboard.

5. Remove the processor and the heatsink and fan

Now its time to remove the heatsink from the motherboard. Generally, the CPU fan and the heatsink attach together. If it is separated in that case, you need to remove the fan first after that, you can remove the CPU heatsink.

In the final step, unlock the processor socket and remove the processor from the motherboard carefully.

6. Remove hard disk and CD/ DVD drives

Its time to remove the other parts of the computer system. Remove the Hard disk drive or SSD from the motherboard. You can also remove the CD/DVD drive from the CPU case.

Sometimes, to remove CD/DVD drive from the CPU case, you need to remove the front cover of the CPU cabinet case first. After that, you can remove the ROM drives.

7. Remove memory modules

In this process, you do remove the RAM from the motherboard. First, unlock the RAM from both ends and pull the RAM carefully.

8. Remove the Power Supply Unit (PSU)

Already you know, SMPS supplies power to the various parts of the computer system. Here you need to remove the SMPS from the CPU cabinet case.

9. Remove the motherboard

The final step of the PC disassemble process is this one. Carefully remove the motherboard from the CPU cabinet case.

Note: Remember, bolts or screws are the very essential things. They help to make rigid, all the parts used inside the computer. To remove any part from the computer system mostly, you need to take out bolts first. Here in PC disassemble steps, I have ignored that portion.

Conclusion:

Assembling and disassembling a computer system is not a difficult task but requires keen observation and knowledge of the different components of the system. You need to be extra careful when fitting in these components and make sure that they are not fitted forcefully but firmly.

In case of hardware failure or to install new add-on cards, you need to have good knowledge to assemble and disassemble a computer system.

Once you have assembled your computer system, the next step is to install the Operating System so that you can start using the computer.

Name: Amit Kumar Mishra

ld: B319005

Branch: CSE